CARPET BADGER

Replacement Cable Instructions



Remove four bolts that secure motor housing to base plate.



Remove motor housing from base plate assembly and set aside.



Remove two allen bolts that secure motor to motor housing.



Remove motor from motor housing.



Remove key chuck retainer with a screwdriver and remove cable.



While motor is clear from assembly grease spool liberally.



Feed cable into spool as shown.





Feed end of cable into spool retainer clip as shown. Pull cable length for secure fit.

Repeat step 1-4 in reverse order. Always wind cable uniformly.

Copyright ©Carpet Concepts, LLC 2012. All Rights Reserved.